

Apple Cleaning & Sanitizing on Packing Line Guide

Condition	Dump Tank	Cleaner	Sanitizer	Fungicide	Coating	Comments
Very Little Calcium & Some Loose Soil	<i>Agchlor 310</i> 50 –100 PPM Total 20 -50 PPM Min. Free <i>DECCO Buffer 312 or 313 or 314</i> pH 6.5 to 7.5	<i>F&V Kleen 241 or 340</i> 7-8 pH	<i>Peraclean</i> 80 – 100 PPM PAA	<i>DECCO Salt#19</i> Line Spray 600 PPM Wax Spray 1000 – 2000 PPM or <i>Penbotec 400SC</i> Line Spray 1000 PPM Wax Spray 2000 PPM	Carnauba or Shellac Consult DECCO Rep	Rinse completely before wax. Waste Water Discharge must comply with Safe Drinking Water Act
Calcium & Mineral Deposits	<i>DECCO Buffer 312 or 313 or 314</i> 2 – 3 pH	<i>Apl Kleen 245 or 246</i> 2 – 3 pH	<i>Peraclean</i> 80 – 100 PPM PAA	<i>DECCO Salt#19</i> Line Spray 600 PPM Wax Spray 1000 – 2000 PPM or <i>Penbotec 400SC</i> Line Spray 1000 PPM Wax Spray 2000 PPM	Carnauba or Shellac Consult DECCO Rep	Rinse completely before wax. Waste Water Discharge must comply with Safe Drinking Water Act
Natural Wax	<i>F&V Kleen 440 or 441</i> 10 – 12 pH	<i>F&V Kleen 440 or 441</i> 10– 12 pH	<i>Peraclean</i> 80 – 100 PPM PAA	<i>DECCO Salt#19</i> Line Spray 600 PPM Wax Spray 1000 – 2000 PPM or <i>Penbotec 400SC</i> Line Spray 1000 PPM Wax Spray 2000 PPM	Carnauba or Shellac Consult DECCO Rep	Rinse completely before wax. Waste Water Discharge must comply with Safe Drinking Water Act
Organic Very Little Calcium & some Loose Soil	<i>Agchlor 310</i> 50 PPM Total Max 20 PPM Free Min <i>Citric Acid</i> pH 6.5 to 7.5	<i>DECCONatur Kleen</i> 10-12 pH	<i>Peraclean</i> 80 – 100 PPM PAA	Bio-Save 10LP 500 gr / 80 Gal Water	<i>DECCONatur 575 – Shellac 520 – Blend 550 - Beeswax</i>	Rinse completely Waste Water Discharge must comply with Safe Drinking Water Act
Organic Calcium Mineral Deposits	<i>Citric acid</i> 2 – 3 pH	<i>DECCONatur Kleen</i> 10-12pH	<i>Peraclean</i> 80 – 100 PPM PAA	Bio-Save 10LP 500 gr / 80 Gal Water	<i>DECCONatur 575 – Shellac 520 – Blend 550 - Beeswax</i>	Rinse completely Waste Water Discharge must comply with Safe Drinking Water Act

Pears Cleaning & Sanitizing on Packing Line Guide

Dump Tank	Cleaners	Sanitizer	Fungicide	Coating	Comments
Pear Float Spec Grav.- Depends on variety pH 11.0 13.0 DECCOSOL 122 14.5% SOPP-	F&V Kleen 241 or F&V Kleen 340 7-8 pH	Peraclean 80 – 100 PPM PAA	DECCO Salt#19 Line Spray 600 PPM Wax Spray 1000 – 2000 PPM Penbotec 400SC Line Spray 1000 PPM Wax Spray 2000 PPM	Carnauba Blend Pear Kote	Waste water Discharge must comply with Safe Drinking Water Act

Cherries & Stone Fruit Cleaning & Sanitizing on Packing Line Guide

Receiving Hydro Cooler	Dump Tank	Cleaners	In-Line Hydro Cooler Sanitizer	Fungicide	Coating	Comments
Agchlor 310 50 –100 PPM Total 20 -50 PPM Min. Free DECCO Buffer 312 or 313 or 314 pH 6.5 to 7.5	Agchlor 310 50 –100 PPM Total 20 -50 PPM Min. Free DECCO Buffer 312 or 313 or 314 pH 6.5 to 7.5	F&V Kleen 241 or F&V Kleen 340 7-8 pH	Peraclean 80 – 100 PPM PAA	Bio-Save 10LP 500 gr / 80 Gal Water	PNPL 255- Veg Oil Base 282 – Min Oil Base Multi Lustr- Blend	Waste water Discharge must comply with Safe Drinking Water Act